

CM Air hoist accessories

Filter-lubricator units

- Filter-lubricator provides necessary clean, lubricated air for air hoist operation
- Unit installs in air supply line, as close as possible to hoist
- Recommended 90 PSIG for all CM air hoists



Filter-lubricator unit

For more information contact:
 American Crane & Equipment Corp.
 Authorized Distributor
 Tel: 877-503-2972
 Fax: 484-945-0430
 sales@americancrane.com
 www.americancrane.com

Filter-regulator-lubricator units

- Used where air line pressure exceeds 115 PSIG
- Installs like filter-lubricator to maintain proper pressure



Filter-regulator-lubricator unit

Filter-lubricator units specifications

Product code	Inlet/outlet size (in.)	Bowl size (oz.)	Approx. shipping weight (lbs.)
902960	3/8	11	8
902961	1/2	11	8
902962	3/4	24	12
902963	1	24	12

Filter-regulator-lubricator units

Product code	Inlet/outlet size (in.)	Bowl size (oz.)	Approx. shipping weight (lbs.)
902966	3/8	11	14
902967	1/2	11	14
902968	3/4	24	18
902969	1	24	18

Bullard hooks

- Bullard hooks may be preferred to standard hooks equipped with latches
- Rugged cast swing gate locking member
- Must be ordered separately from hoists
- Hook gate is intended to retain slings and other lifting devices under slack conditions only. Gate is not intended to retain the load.



* WARNING

Overloading and improper use can result in injury.

To avoid injury:

- Do not exceed rated load (capacity) or working load limit.
- Do not use to lift people or loads over people.
- Use only alloy chain for overhead lifting.
- Read and follow all instructions.